

PerfectFit® Shutter Lite

Measuring guide

You will need:

- Tape measure
- Ordering device/pad and pen
- PF shutter bracket
- Credit card


1. Check the bracket fits into the gasket of the glass.




2. Measure from the edge of the windowpane around the PVC frame, ensuring a 23mm clearance around the frame. This will ensure the panel fits between the brackets.



3. Measuring the visible glass size; take 3 measurements from the bottom, middle and top of the glass size width and make a note of the smallest measurement.



4. Do the same for the visible glass size height, taking measurements from the left, middle and right of the glass and making a note of the smallest measurement.



5. Place a credit card over the corner of the window where the glass meets the gasket and take a note of the measurement from the glass to the edge of the card, this will be your bead depth and will determine what size bracket to use.



6. If the window has a handle on the left or right or bottom of your window, then measure from the gasket upwards to the centre of the handle plate.



7. Select the tilt rod side (left or right). If the panel requires a handle, you must always select the tilt rod on the opposite side.




Panels cannot be aligned and matched if side by side and have slightly different drops – be clear with customer on louvre alignment if panels have different drops.



Panel Configuration

Where the glass width exceeds the maximum for a single panel the shutter will be manufactured using multiple panels. As depicted below:



Glass size 150cm

Panel Quantities

- If Width = <75cm panel quantity = 1
- If Width = >75 Panel quantity =2
- If Width = >160 panel quantity = 3

Where a bottom handle rebate is required the panel count must be odd. The below should be used in place of the above

- If width = >75cm panel quantity = 3

PerfectFit® Shutter Lite Installation guide

You will need:

- Stanley knife to open the packaging
- Credit card
- Product & brackets

1. Open the packaging but be careful not to damage the product.



2. Check that your delivery matches up to your order – check the correct number of panels, tilt rods and handle recesses in the right place. If there is anything missing, broken or incorrect versus the order. Contact the Customer Service Centre to raise a spare or a remake.



2. Using a credit card as a guide slot a bracket into the corner of each bracket seal on the bottom of the window.



3. Repeat the above for the top of the window.



4. Once all the brackets are in place the PerfectFit® Shutter is ready to be installed. Observe the label on the panel noting the 'TOP' of the blind. Ensure you install the blind the right way around.



5. Line up the cut outs in the bottom frame with the bottom brackets, clip the brackets into the holes in the frame.



6. Once the bottom frame is clipped in, push the top side of the frame into the top brackets.



7. Your PerfectFit® Shutter is now installed.



TIP: For drops above 90cm a side bracket is required. A bracket hole should be centralised unless obstructions from rebates or mid-rails are present in which case the punch should be positioned 20cm above the obstruction.

TIP: If you are installing a window with multiple panels, ensure you install from left to right. If you need to remove the panels, remove from right to left. This ensures the astragal that join the panels and reduce light ingress if fitted together correctly.

